NTN: ACM Sample Change-out (refer to SOP for complete instructions:

http://nadp.slh.wisc.edu/lib/manualsSOPs.aspx



Trigger sensor with water/snow/ice.



Use lid bag to place new, clean lid on the deployed bucket.



Seal lid on bucket using lid bag as a glove.



Remove sealed bucket from collector and set aside.



Deploy new, clean bucket using bucket bag as a glove.

Facing away from the collector, blow moisture from surface of sensor, allowing the collector to close.

Complete blocks 1-4, and 10 of the field form.

Take the sealed bucket to the field laboratory to weigh and decant the sample for shipment to the CAL for analysis.

