
NTN: Sample Decanting

(refer to SOP for complete instructions:

http://nadp.slh.wisc.edu/lib/manualsSOPs.aspx




Weigh bucket, lid, and sample. Complete block 6 of FORF.




Remove lid. Inspect sample for debris. Complete block 5 of FORF.



Decant sample into 1-L bottle from new, clean supplies. Avoid decanting debris. Dispose of excess sample.



Place matching bar code labels on FORF and bottle bag (or dry week envelope).



Complete the FORF.

If site has an electronic raingage, <u>and</u> data has been uploaded to NADP, block 7 can be completed using the tool at:

http://nadp.slh.wisc.edu/precip/

Place FORF and bagged 1-L bottle in shipping box (or FORF in a dry sample envelope) and ship to:

Central Analytical Laboratory 2601 Agriculture Drive Madison, Wisconsin 53718